



-001 INSTL.

5. STATIONS SHOWN ARE A/C FUSELAGE STATIONS.

4) INSTALL TOP EDGE OF CHAFE STRIP EVEN WITH EDGE OF STEP.

3) INSURE STEP LIGHT DRAIN HOLE IS NOT OBSTRUCTED UPON INSTALLATION OF CHAFE STRIP.

2) BOND CHAFE STRIP TO TANK SHELL USING AEROSIL PUTTY FILLER OR CB 200 ACRYLIC ADHESIVE.

1) SAND AREAS OF TANK SHELL TO BE BONDED WITH 80 GRIT WET OR DRY.

NOTES:

NO. REQ'D PER ASSY	PART NO.	NAME	STOCK SIZE	MATERIAL	MATL.SPEC	ZONE
	1 41228-202-067-002	R/H CHAFE STRIP				
	1 41228-202-067-001	L/H CHAFE STRIP				
-001	41228-203-052-001	INSTL.				
LIST OF MATERIAL						
PROPRIETARY RIGHTS NOTICE				UNLESS OTHERWISE SPECIFIED	T. HARVILLE	
					DRAFTSMN	7/7/93
THESE DATA ARE PROPRIETARY TO ERA AVIATION, INC.				CHECK		
DISCLOSURE, REPRODUCTION, OR USE OF				XX.±.03		
THESE DATA FOR ANY PURPOSE IS FORBIDDEN WITHOUT WRITTEN AUTHORIZATION FROM ERA AVIATION, INC.				XXX.±.010		
THE FOREGOING NOTES NOT APPLY TO VENDOR PARTS.				ANGLES ±.1/2"		
-001	1	41228-200-004				
DASH NO.	REQ'D PER ASSY	NEXT ASSEMBLY	MDL	HEAT TREAT	INSTALLATION CHAFE STRIP	
				FINISH	DWG. NO.	REV.
					41228-203-052	IR



Era Aviation, Inc.